MallinCam Wireless Exposure Control Instructions



Receiver

- o <u>Power ON</u> Push "POWER" for 3-4 Seconds
- Change Channel
 Push Both Buttons for 3-4 Seconds
 Display Flashes
 Select Channel Number



Transmitter

- o Power ON Press ANY Button
- Channel Selection
 Push Left or Right Arrow to get CH"
 Push Center Key Display Starts
 Flashing

Push Up or Down Key - Match Channel to that of Receiver Push Center Key – Channel Selected is Locked

• Long Exposure

- o Push Left or Right Arrow to get "Long"
- Push Center Key Last two digits start to Flash
- o Push Up Arrow to Select Time
- Push Center Button Exposure Locked
- Depress Upper/Right Button to Start Exposures
- Depress Upper/Right Button to Stop Exposures

Note:

- Depress Upper/Left Transmitter
 Button for 4 Seconds to Illuminate
 the Display
- To confirm Image Integration and Transfer: Receiver LED Solid Red During Exposure
 - Receiver LED Green During Image Transfer
 - Receiver LED Returns to RED after Image Transfer
- At the End of the Observing Session, Turn Off the Receiver by Pressing "POWER" for 4 Seconds. The Hand Controller (Transmitter) Turns OFF Automatically in One Minute